

MULTI-PURPOSE WEATHERSTRIPPING TAPE

TOOLS NEEDED:



INSTRUCTIONS:



INSTALLATION DETAILS:

Temperature of surfaces to be sealed must be above 40 ° F. DO NOT apply to unpainted wood frames. DO NOT apply to wallboard, plaster, veneer panelling, mahogany moulding or peeling paint. DO NOT stretch when applying.



M-D Canada, a division of M-D Building Products

Headquarters


5720 Ambler Drive, Mississauga, ON, L4W 2B1
1-800-565-6653 | service@mdteam.com

Retail Distribution Center

2994 Peddie Rd, Unit 2, Milton, ON L9T 6Y9
1-888-908-1036 | retailorders@mdteam.com

RUBAN ADHÉSIF ISOLANT TOUT USAGE

OUTILS NÉCESSAIRES :



INSTRUCTIONS :



DÉTAILS POUR L'INSTALLATION :

La température des surfaces à sceller doit être supérieure à 4 ° C. NE PAS appliquer sur les cadres de bois non peints. NE PAS appliquer sur les panneaux muraux , le placoplâtre, le placage, les moulures en acajou ou la peinture écaillée. NE PAS étirer en l'appliquant.



M-D Canada, une division de M-D Building Products

Siège social

5720 Ambler Drive, Mississauga (Ontario) L4W 2B1
1 800 565-6653 | service@mdteam.com

Centre de distribution au détail

2994 Peddie Road, Unit 2, Milton (Ontario) L9T 6Y9
1 888 908-1036 | retailorders@mdteam.com