

## MULTI-PURPOSE DENIM INSULATION

### TOOLS NEEDED:



### INSTRUCTION DETAILS:

1. Measure.
2. Trim to size.
3. Install in desire area.



*M-D Canada, a division of M-D Building Products*

**Headquarters**

5720 Ambler Drive, Mississauga, ON, L4W 2B1  
1-800-565-6653 | [service@mdteam.com](mailto:service@mdteam.com)

**Retail Distribution Center**

2994 Peddie Rd, Unit 2, Milton, ON L9T 6Y9  
1-888-908-1036 | [retailorders@mdteam.com](mailto:retailorders@mdteam.com)

## ISOLANT TOUT-USAGE EN DENIM

### OUTILS NÉCESSAIRES :



### DÉTAILS POUR L'INSTALLATION :

1. Mesurer.
2. Couper à la longueur désirée.
3. Installez dans la zone souhaitée.



*M-D Canada, une division de M-D Building Products*

*Siège social*

5720 Ambler Drive, Mississauga (Ontario) L4W 2B1  
1 800 565-6653 | [service@mdteam.com](mailto:service@mdteam.com)

*Centre de distribution au détail*

2994 Peddie Road, Unit 2, Milton (Ontario) L9T 6Y9  
1 888 908-1036 | [retailorders@mdteam.com](mailto:retailorders@mdteam.com)