

REPLACEABLE CAULK CORD WEATHERSEAL

INSTRUCTIONS:



INSTRUCTION DETAILS:

1. Make sure surface is clean & free of dirt, moisture, grease, and old caulk.
2. Carefully peel top layer of cord beads. Separate individual beads according to desired width of gap.
3. Press cord into opening and form to desired shape. For large gaps, use several cord beads.
4. Place unused cord back in carton for future use.



M-D Canada, a division of M-D Building Products

Headquarters

5720 Ambler Drive, Mississauga, ON, L4W 2B1
1-800-565-6653 | service@mdteam.com

Retail Distribution Center

2994 Peddie Rd, Unit 2, Milton, ON L9T 6Y9
1-888-908-1036 | retailorders@mdteam.com

CORDON À CALFEUTRER REMPLAÇABLE

INSTRUCTIONS :



DÉTAILS POUR L'INSTALLATION :

1. Assurez - vous que la surface est propre et exempte de saleté, d'humidité, de graisse ou de vieux calfeutrage.
2. Peler délicatement la couche supérieure des ficelles du cordon. Séparer les ficelles individuelles en fonction de l'espacement désiré.
3. Enfoncez le cordon dans l'ouverture et créez la forme désirée. Pour les grands espacements , utilisez plusieurs cordelettes.
4. Remplacez le cordon inutilisé dans l'emballage pour une utilisation ultérieure.



M-D Canada, une division de M-D Building Products

Siège social

5720 Ambler Drive, Mississauga (Ontario) L4W 2B1
1 800 565-6653 | service@mdteam.com

Centre de distribution au détail

2994 Peddie Road, Unit 2, Milton (Ontario) L9T 6Y9
1 888 908-1036 | retailorders@mdteam.com